

## Application Note *How to use the TOMBAK as a standalone 20MHz generator*

### Multiboard Series

*TOMBAK : Synchronization electronic board*



# How to use the TOMBAK as a standalone 20MHz generator

**Pre-requirement:** Before using the TOMBAK board, make sure you followed all the instructions mentioned in the Operating Manual

## 1. Presentation

An internal 200MHz generator is available and does not need any external signal. The board can output an external signal up to 20MHz with adjustable pulse width.

## 2. Timing Diagram




Figure 1 : internal 200MHz clock divided by 10 to get a duty cycle software adjustable 20MHz output signal

## 3. Synoptic





Figure 2 : Main firmware features used in Standalone Generator


## 4. Cabling

1. Plug the USB-Jack cable in the “*USB In*” connector
2. The software adjustable signal will output on the “*Pulse Out*” SMA connector
3. Finally, plug the power supply to the “*Power In*” connector to power on the board




## 5. Software configuration

Launch the ALPhANOV Control Software and click on *Connect* to start the TOMBAK hardware detection. The software automatically detects the TOMBAK board.




**A window will appear for each TOMBAK connected to the computer.**

The main configuration windows must be configured as follow :



- Working Mode window :
  - Set the **Board** **On**
  - Set the **Shaper** button to **Off**
  - Set the **Inverse** button to **Off** unless you need to invert the output signal
  - Select **Gen** mode in **Advanced Mode**




- Input pulse window :
  - **Threshold** input voltage is not used in this configuration, set value to 0V (default settings)
  - **Delay** value is not used in this configuration, set value to 0V (default settings)
  - Set **Source** to **Direct** (default settings)

- **Pulse Freq.** indicator give the internal rate generator. The output frequency is related to this primary value.
- Set the **Division** factor according to the following definition :

$$\text{Division}^{(*)} = \frac{\text{Pulse Freq(Hz)}}{\text{Output frequency(Hz)}}$$


(\*) Division must be at least 10 as the maximum output frequency is 20MHz.




*In this example, the division is set to 100 to get a 2Mhz output frequency => 200Mhz/2Mhz = 100*

- Output Pulse window :
  - **Delay** value is not used in this mode
  - **Auto Fine Delay** is not used in this mode
  - Choose the output **pulse width** to get a specific duty cycle (\*).

$$\text{pulse width (s)}^{(*)} = \frac{\text{DutyCycle(\%)}}{100 * \text{OutputFrequency(Hz)}}$$




- Synchro input windows:
  - Source : Not used in this mode
  - Mode : None
  - Frequency : Not used in this mode
  - Burst size : Not used in this mode



- Synchro output window (default settings) :
  - Source : Pulse



Don't forget to save the settings by clicking on the "Save" button in the bar menu.



## 6. Main features

Adjustable output frequency	[0 – 20MHz]
Frequency resolution (N is an integer in the range [10 – 10 <sup>9</sup> ])	$\frac{\text{Internal 200Mhz clock}}{N}$
Adjustable pulse width ⇒ resolution (pulse width [5ns – 510ns]) ⇒ resolution (pulse width [511ns – 2 <sup>62</sup> ns])	[5ns – >>1000s] 2ns 5ns
Output Voltage	1 / 3,3 / 5 Volts (hardware setup)
Maximum output frequency	20 MHz